


Continue





































In Chromebook or tablet mode, there are some actions you can take on it:

- Click: Tap where you want to click.
- Right-click: Touch and hold your finger up, down, right, or left.
- Go back: Swipe your finger from left to right.
- To go forward: swipe from right to left.

Zoom in/out: Touch and hold an area with 2 fingers. To zoom in, spread them apart. To zoom out, pinch them together. Show your row of apps (shelf): Swipe up from the bottom of the screen. Hide your row of apps (shelf): Long press on the row of apps on the bottom of the screen. View two apps side by side: If you see all your open windows on the screen, drag an app to the left or right to use it next to another app. Open and close windows and tabs

Open a new window: In the top-right corner of the window, tap More New Window. Open a new tab: Next to your open tab, tap New Tab. Close window or tab: Swipe down from the top of the screen to see all of your open windows. Then swipe down on a window to close it. Reopen a window or tab you closed: At the top, next to a tab, tap and hold. Select Reopen closed tab. See two windows at the same time From the top of the screen, swipe down to see an overview of your windows. Drag one of the windows you want to use to the left or right edge of the screen. Tap the other window you want to use. To adjust the sizes of the two windows, drag the line at the center of the split screen. To remove split screen, drag the line at the center of the split screen to either side. Tip: At the bottom right, you can also touch and hold Overview . Reorder , move , or pin tabs You can put related tabs together, or move a tab into or out of a window. Also, if you have several tabs open, you can group similar ones together. When you're done grouping, drag the group icon to the shelf. Drag the group's name to the shelf. Zoom in/out: On a desktop computer, double-click the mouse wheel to zoom in or out. Or, while viewing a webpage, scroll over the page with your finger until you find what you want to view. Then, from the top of the new window, drag the bar over the window you want to add it to. When you release the tab, it merges with the existing window. Move a tab from one split-screen window to another: When in split-screen, drag the tab away from the window and over to the other half of the screen. It can be added to an existing Chrome window, or become the new split-screen window. Pin a tab in place: Tap and hold the tab you want to pin to see the menu. Select Pin tab. Pinned tabs appear on the left side of your browser window, and are smaller. Fix touchscreen problems If your touchscreen isn't working, try these steps. Test after each step to see whether your touchscreen works. If these steps don't fix the problem, contact your Chromebook manufacturer. Post to the help community Get answers from community members Share copy and redistribute the material in any medium or format for any purpose, even commercially. Adapt remix, transform, and build upon the material for any purpose, even commercially. The licensor cannot revoke those freedoms as long as you follow the license terms. Attribution You must give appropriate credit, provide a link to the license, and indicate if changes were made. You may do so in any reasonable manner, but not in any way that suggests the licensor endorses you or your use. ShareAlike If you remix, transform, or build upon the material, you must distribute your contributions under the same license as the original. No additional restrictions You may not apply legal terms or technological measures that legally restrict others from doing anything the license permits. You do not have to comply with the license for elements of the material in the public domain or where your use is permitted by an applicable exception or limitation. No warranties are given. The licensee may not give you all of the permissions necessary for your intended use. For example, other rights such as publicity, privacy, or moral rights may limit how you use the material. Hi @Sarah! Welcome to our community! We'll get your feedback taken care of soon. I'm glad you found our guide helpful. Please let us know if we can assist further. Your input helps us improve our guides to better serve everyone. Thank you for taking the time to help resolve the problem!

Check for Software Updates Open your Chromebook Go to Settings > About Chrome OS > Check for updates. Install any pending updates and restart your Chromebook.2. Test the Touchscreen in Recovery Mode Turn off your Chromebook Press Esc + Refresh () and then the Power button to enter Recovery Mode. Once in Recovery Mode, check if the touchscreen responds. If it works, the issue might be with Chrome OS settings. If it doesn't, the issue is likely hardware-related.3. Powerwash and Enable Developer Mode Perform a Powerwash.Go to Settings > Advanced > Reset settings > Powerwash.If the problem persists, enable Developer Mode: Turn off your Chromebook Press Esc + Refresh () and the Power button. When the recovery screen appears, press Ctrl + D and follow the instructions. Enabling Developer Mode might reset deeper system configurations, which could resolve the issue.4. Check Internal Touchscreen Settings Open the Chrome browser and type:chrome://flags/#ash-debug-shortcutsEnable the ash-debug-shortcuts option. Use the debug shortcuts to test touchscreen functionality.5. Perform a Hardware Diagnostic Test Turn off your Chromebook Press Esc + Refresh () and the Power button to access diagnostics. Select Test Touchscreen if available.If your Chromebook doesn't support diagnostics, use external HP diagnostic tools.6. Inspect for Physical or Hardware Damage Ensure the screen is clean and free from debris. Gently clean the touchscreen with a soft, lint-free cloth. Check for cracks or visible damage that might affect touch response.7. Hard Reset Your Chromebook Turn off your Chromebook Press and hold Refresh () and tap the Power button. Release the keys and wait about 30 seconds before turning the device back on.8. Contact Support If none of the above steps work, reach out to Google Support or your local retailer for assistance.9. Feedback Loop Provide feedback through the Help Center or forums to share your experience and contribute to future improvements.

The touchscreen stops working, it could be as simple as a dirty screen, but certain software and system settings can affect how the touchscreen works, too. Below are all the fixes we recommend for an unresponsive touchscreen on a Chromebook. In most cases, you can fix the touchscreen on your Chromebook yourself. Follow these steps in order, testing the screen after each one to see if it works: Restart the Chromebook. If the touchscreen stopped working because of a temporary software-related issue, a reboot is a great first step to try.Through that link are directions for how to hard reset the Chromebook, which you should also try if a normal restart doesn't fix the touchscreen. Clean the screen. Shut down your Chromebook, and thoroughly clean the screen using a lint-free cloth. The steps are similar to cleaning the screen on an iPad. Be careful to remove any dirt or debris, food crumbs, or sticky residues, and dry the screen if it has any liquid on it. If the screen is filthy, you can use a cleaning solution specifically designed for LCD screens and a microfibre cloth. Use as little liquid as possible, and don't drip on the keyboard or allow the cleaning solution to run down behind the screen. Finish up by completely drying the screen with another microfibre cloth.Never use any cleaning product that includes ammonia, ethyl alcohol, acetone, or anything else that isn't designed for use with Chromebook touchscreens. Clean and dry your hands. Before trying your touchscreen again, make sure your fingers aren't sticky and are free from dirt or the touchscreen may not function correctly. Make sure the touchscreen isn't off. Chromebooks have the option to toggle the touchscreen on and off. If you accidentally do this, the screen will stop responding to your touch until it's turned back on. To activate the Chromebook touchscreen toggle, press Search + Shift + T.You might need to enable a Chrome flag for this shortcut to work. Navigate to chrome://flags/#ash-debug-shortcuts and enable Debugging keyboard shortcuts. Update the Chromebook. The latest version of Chrome OS includes fixes for all known software bugs, one of which could be contributing to the touchscreen not working. Reset your Chromebook to factory settings. If your touch screen still doesn't work, the next step is to reset it to factory settings.This process, called powerwashing, will remove all local data, so make sure you've backed up any local files to your Google Drive. If your touchscreen still isnt working even after a full powerwash, contacting the manufacturer or bringing your Chromebook to a professional for repairs might be a good idea. A technician is best equipped to deal with this sort of hardware issue. If your touchscreen is working, but it acts up by registering touches in the wrong place, that usually a sign of a hardware problem, too. So, in both cases, its likely something related to the physical components of your device. Chromebooks are easy to use and easy to fix. Here are the most common reasons that Chromebook touchscreens stop working: Software problems: Most Chromebook software issues can be resolved through a restart or a factory reset.Dirt or debris on the screen: If the screen is dirty, the touchscreen functionality may not work. The same is true if your hands are dirty or wet.System settings: The touchscreen may have been disabled accidentally, in which case you can fix the problem by re-enabling it.Hardware problems: The touchscreen digitizer or other hardware may have failed.FAQUse the keyboard shortcut Search+Shift+T to lock your Chromebook touchscreen. You might need to go to chrome://flags/#ash-debug-shortcuts and enable debugging keyboard shortcuts to use it. This option isn't available on every Chromebook.If the touchpad on your Chromebook isn't working, try pressing the Esc key several times. Some Chromebooks have function keys that can turn the touchpad on and off. If you have keyboard shortcuts enabled, press Search+Shift+P to toggle the touchpad.Thanks for letting us know!Get the Latest Tech News Delivered Every DaySubscribeTell us why!How can financial brands set themselves apart through visual storytelling?Our experts explainhow.LearnMoreThe Motorsport Images Collections captures events from 1895 to today's most recent coverage.Discover The CollectionCurated, compelling, and worth your time.Explore our latest gallery of Editors Picks.Browse Editors' FavoritesThomas Matis was a didy tell us if it ever worked and if anything happened prior to it no longer working. The first steps if your touchscreen stopped working is to A: Reset your Chromebook hardware and B: reset your Chromebook to factory settings. Let us know what you have tried. When your Chromebook touchscreen stops working, it could be as simple as a dirty screen, but certain software and system settings can affect how the touchscreen works, too. Below are all the fixes we recommend for an unresponsive touchscreen on a Chromebook. In most cases, you can fix the touchscreen on your Chromebook yourself. Follow these steps in order, testing the screen after each one to see if it works: Restart the Chromebook. If the touchscreen stopped working because of a temporary software-related issue, a reboot is a great first step to try.Through that link are directions for how to hard reset the Chromebook, which you should also try if a normal restart doesn't fix the touchscreen. Clean the screen. Shut down your Chromebook, and thoroughly clean the screen using a lint-free cloth. The steps are similar to cleaning the screen on an iPad. Be careful to remove any dirt or debris, food crumbs, or sticky residues, and dry the screen if it has any liquid on it. If the screen is filthy, you can use a cleaning solution specifically designed for LCD screens and a microfibre cloth. Use as little liquid as possible, and don't drip on the keyboard or allow the cleaning solution to run down behind the screen. Finish up by completely drying the screen with another microfibre cloth.Never use any cleaning product that includes ammonia, ethyl alcohol, acetone, or anything else that isn't designed for use with Chromebook touchscreens. Clean and dry your hands. Before trying your touchscreen again, make sure your fingers aren't sticky and are free from dirt or the touchscreen may not function correctly. Make sure the touchscreen isn't off. Chromebooks have the option to toggle the touchscreen on and off. If you accidentally do this, the screen will stop responding to your touch until it's turned back on. To activate the Chromebook touchscreen toggle, press Search + Shift + T.You might need to enable a Chrome flag for this shortcut to work. Navigate to chrome://flags/#ash-debug-shortcuts and enable Debugging keyboard shortcuts. Update the Chromebook. The latest version of Chrome OS includes fixes for all known software bugs, one of which could be contributing to the touchscreen not working. Reset your Chromebook to factory settings. If your touch screen still doesn't work, the next step is to reset it to factory settings.This process, called powerwashing, will remove all local data, so make sure you've backed up any local files to your Google Drive. If your touchscreen still isnt working even after a full powerwash, contacting the manufacturer or bringing your Chromebook to a professional for repairs might be a good idea. A technician is best equipped to deal with this sort of hardware issue. If your touchscreen is working, but it acts up by registering touches in the wrong place, that usually a sign of a hardware problem, too. So, in both cases, its likely something related to the physical components of your device. Chromebooks are easy to use and easy to fix. Here are the most common reasons that Chromebook touchscreens stop working: Software problems: Most Chromebook software issues can be resolved through a restart or a factory reset.Dirt or debris on the screen: If the screen is dirty, the touchscreen functionality may not work. The same is true if your hands are dirty or wet.System settings: The touchscreen may have been disabled accidentally, in which case you can fix the problem by re-enabling it.Hardware problems: The touchscreen digitizer or other hardware may have failed.FAQUse the keyboard shortcut Search+Shift+T to lock your Chromebook touchscreen. You might need to go to chrome://flags/#ash-debug-shortcuts and enable debugging keyboard shortcuts to use it. This option isn't available on every Chromebook.If the touchpad on your Chromebook isn't working, try pressing the Esc key several times. Some Chromebooks have function keys that can turn the touchpad on and off. If you have keyboard shortcuts enabled, press Search+Shift+P to toggle the touchpad.Thanks for letting us know!Get the Latest Tech News Delivered Every DaySubscribeTell us why!If [Chromebook] Troubleshotting - Abnormalities with the Chromebook TouchScreen If you encounter touchscreen issues, such as insensitivity or abnormal clicking when using your Chromebook, this article provides some possible causes and solutions.Verify if your Chromebook supports touch screen functionBefore troubleshooting, you can first check if your Chromebook supports touchscreen function through the ASUS official website.Go to the ASUS official website, click on the [Search] icon, and then enter your product model name. If you are unsure about your Chromebook's product model, please refer to this article: How to check the models name.(The following steps use the model CX3400 as an example)After entering the product page, click on [Tech Specs].In the Tech Specs page, you can find information on touchscreen/stylus support in the Display specification column.If the touchscreen is not functioning properly, it is recommended to follow the following steps to confirm whether the touchscreen can function properly:Step 1 : Clean the screenMake sure there is no dust or stains on the screen. If it is not cleaned regularly, the touchscreen may accumulate dust or stains over time, which may cause it to malfunction. If you need to clear the screen, please refer to the following steps:Please turn off the computer first, and carefully check the condition of the screen for any external damage.Spray the screen cleaner onto a soft and clean cloth, and gently wipe the screen to remove any stains or particles.Note: Only make the cloth slightly damp, and do not spray the cleaning liquid directly on the screen itself, as water marks may remain on the screen. If you do not have a screen cleaner, you can use a microfiber cloth to clean the screen naturally. After wiping the screen, ensure the touchscreen function is normal.Note: To avoid this problem from happening again, always use approved cleaning products and methods. If your computer does not respond to touch gestures, it is recommended to troubleshoot the reason causing the touchscreen sensitivity loss. The ChromebookTroubleshooting - Abnormalities with the Chromebook TouchScreen If you encounter touchscreen issues, such as insensitivity or abnormal clicking when using your Chromebook, this article provides some possible causes and solutions.Verify if your Chromebook supports touch screen functionBefore troubleshooting, you can first check if your Chromebook supports touchscreen function through the Asus official website.Go to the ASUS official website, click on the [Search] icon, and then enter your product model name. If you are unsure about your Chromebook's product model, please refer to this article: How to check the models name.(The following steps use the model CX3400 as an example)After entering the product page, click on [Tech Specs].In the Tech Specs page, you can find information on touchscreen/stylus support in the Display specification column.If the touchscreen is not functioning properly, it is recommended to follow the following steps to confirm whether the touchscreen can function properly:Step 1 : Clean the screenMake sure there is no dust or stains on the screen. If it is not cleaned regularly, the touchscreen may accumulate dust or stains over time, which may cause it to malfunction. If you need to clear the screen, please refer to the following steps:Please turn off the computer first, and carefully check the condition of the screen for any external damage.Spray the screen cleaner onto a soft and clean cloth, and gently wipe the screen to remove any stains or particles.Note: Only make the cloth slightly damp, and do not spray the cleaning liquid directly on the screen itself, as water marks may remain on the screen. If you do not have a screen cleaner, you can use a microfiber cloth to clean the screen naturally. After wiping the screen, ensure the touchscreen function is normal.Note: To avoid this problem from happening again, always use approved cleaning products and methods. If your computer does not respond to touch gestures, it is recommended to troubleshoot the reason causing the touchscreen sensitivity loss. The ChromebookTroubleshooting - Abnormalities with the Chromebook TouchScreen If you encounter touchscreen issues, such as insensitivity or abnormal clicking when using your Chromebook, this article provides some possible causes and solutions.Verify if your Chromebook supports touch screen functionBefore troubleshooting, you can first check if your Chromebook supports touchscreen function through the Asus official website.Go to the ASUS official website, click on the [Search] icon, and then enter your product model name. If you are unsure about your Chromebook's product model, please refer to this article: How to check the models name.(The following steps use the model CX3400 as an example)After entering the product page, click on

Why won't my touch screen work on my chromebook. Why is my touch screen not working on my acer chromebook. Chromebook toetsenbord werkt niet. Why is my touch screen not working on my chromebook lenovo. Why is my touch screen not working on my dell chromebook. Why isn't my touch screen working on my chromebook. Why is my touch screen not working on my hp chromebook. How to fix chromebook touch screen not working. Why is my touch screen not working on my school chromebook.